

Thank you very much for choosing our AJAZZ Black Jazz AK35i mechanical keyboard. This product has a variety of cool functions and lighting effects. I hope it can bring you a brand new operating experience.

1. Lighting Control Function:

- ★ FN + Del = Backlight switch (includes 4 LED lighting effects)
- ★ FN + INS = Backlight switch (includes 4 LED lighting effects)
- ★ FN + Home = Backlight switch (includes 4 LED lighting effects)
- ★ FN + PgUP = Backlight switch (includes 4 LED lighting effects)
- ★ FN + END = Changing the mode can customize the on and off of each button LED, the default heart-shaped pattern.
- ★ When FN+END enters the change mode, it will restore the last defined effect by default. It will be triggered again to enter the defined LED mode, the indicator will flash, and the trigger button can switch the LED on and off. After the definition is completed, it will be triggered again to exit the definition mode and save the defined structure.
- ★ Support FN + ↑ or FN + ↓ to adjust the brightness of the backlight, 25 levels can be adjusted, long press to continue to the brightest or off.
- Press FN +- or FN ++ to adjust the streaming speed, 25 levels adjustable, long press and keep changing to the fastest or slowest.
- Speed adjustment/brightness adjustment, highest or lowest gear, Caps / Num / Scroll / LED / Game LED flashes 3 times and then exits, all indicator LEDs return to their original state.
- ★ FN + → Flow direction to the right, FN + ← Flow direction to the left.

2. Shortcut key and scroll wheel function description:

- ★ Factory default function of independent button:
A1 key=previous song A2 key=play/pause, A3=next song
M key full key without punch/6 key without punch (factory default full key without punch, the corresponding light is off, press to switch to 6 key without punch, the corresponding light is on)

- ★ The G key is the function switch key: the default function is the volume adjustment mode, and the corresponding scroll wheel rotates upwards to increase the volume, and rotates downward to decrease the volume. (Corresponding to this key, the indicator light is off) After pressing it once, it is the backlight brightness adjustment mode, and the corresponding scroll wheel rotates upwards to increase the brightness, and downwards to decrease the brightness. (Corresponding to this key, the indicator lights up) Press and hold the G button to customize the independent button 1-2-3 in the drive and exit the drive. Press and hold the mode switch button for 1-5 seconds to activate, and the corresponding G indicator light will be on. Long press again for 1.5 seconds and the operation indicator light is off 1-2-3 key to restore to the default function and back to the last backlight state, the configuration environment will also fail.
- If the G button is on in the configuration mode, there is a button that has not been set, it is regarded as the light mode pre-stored button (the default A1 is on).
- Note: In profile mode, the mode switch key is fixed in the volume adjustment state. (The editing object has only 4 independent buttons and 104 regular buttons)
- M key
AJAZZ cloud key (full key without punch/6 key without punch at the factory), follow-up use with ajazz cloud driver.

3. Multimedia and Special Functions Key

- FN + F1=My Computer
- FN + F2=Calculator
- FN + F3=Mailbox
- FN + F4=Search
- FN+ESC Long press to restore factory settings
- FN + PAUSE play pauses the current animation, the animation that can be paused depends on the backlight mode.
- Support FN + WIN to lock WIN&APP, press again to unlock, separate LED instructions.

非常感谢您选购了我们AJAZZ黑爵AK35i刺客II机械键盘，这款产品具备各种酷炫的功能与灯效，希望它能带给您全新的操作感受。

一、灯光控制功能如下：

- ★ .FN + Del 流光溢彩：整体键盘背光按规则动态流动。
A. 模式一；随波逐流。 B. 模式二；峰回路转。
C. 模式三；涌泉相抱。 D. 模式四；波光粼粼。
- ★ .FN + INS 水天一色：整体键盘背光颜色统一变化。
A. 模式一；长亮。 B. 模式二；游戏阶梯。
C. 模式三；呼吸。 D. 模式四；暗隐前行。
- ★ .FN + PgDN 光彩夺目：整体键盘背光为多彩动态变化。
A. 模式一；星光闪烁。 B. 模式二；微波凌凌。
C. 模式三；流星赶月。 D. 模式四；旗帜飞扬。
- ★ .FN + Home 一触即发：触发一次键盘，灯光以按键为中心扩散或点亮。
A. 模式一；泛起涟漪。 B. 模式二；踏雪无痕。
C. 模式三；奔逸绝尘。 D. 模式四；六心连锁。
- ★ .FN + PgUP 青春时代：整体键盘背光快节奏的有规律的灯光变化。
A. 模式一；龙腾虎跃。 B. 模式二；大鹏展翅。
C. 模式三；数码时代。 D. 模式四；推波助澜。


★ .FN + END 指点江山：该模式可自定义每个按键 LED 的亮灭，默认心形图案。FN加END进入该模式时默认恢复上一次定义的效果，再次触发进入定义 LED 模式，指示灯闪烁指示。触发按键可切换 LED 的亮灭，定义完成后再次触发退出定义模式，并保存定义结果。

★ 支持 FN + ↑ 或 FN + ↓ 调节背光亮度，25 级可调，长按持续到最亮或灭。
按 FN + +/- FN + + 调节流彩速度，25级可调，长按持续到最快或最慢。
速度调节/亮度调节，最高或最低档，Caps / Num / Scroll LED / Game LED 闪烁 3 次后退出，所有指示 LED 恢复原来状态。

★ .FN + → 流动方向向右。 .FN + ← 流动方向向左。

二、快捷键及滚轮功能说明：

- ★ 独立按键出厂默认功能：
A1键-上一曲，A2键-播放/暂停，A3键-下一曲，
M键全键无冲/6键无冲（出厂默认全键无冲相应灯灭，按下切换成6键无冲相应灯亮起）



- ★ .G键
G键为功能切换键：默认功能为音量调节模式，相应滚轮向上转动为音量加，想下转动音量减。（对应此键指示灯灭）
按下一次后为背光亮度调节模式，相应滚轮向上转动亮度加，向下转动亮度减。（对应此键指示灯亮起）
长按G键在驱动中自定义好独立按键1-2-3后退出驱动，通过长按模式切换键1.5秒激活，相应G指示灯亮。再次长按1.5秒操作指示灯灭1-2-3键恢复为默认功能并恢复到上一次背光状态，配置环境也将失效。
如在配置模式下G键亮起有按键未进行设置则视为灯光模式预存键（默认A1亮起）注意：配置文件模式下模式切换键固定在音量调节状态。（编辑的对象只有4个独立按键 和104个常规按键）

- ★ .M键：
黑爵云键（出厂时为全键无冲/6键无冲），后续配合黑爵云驱动进行使用。

三、多媒体及特殊键盘功能

- | | | |
|-------------|-------------|--------------|
| FN+F1= 我的电脑 | FN+F5=主页 | FN+F9= 后退 |
| FN+F2= 计算器 | FN+F6=网页收藏夹 | FN+F10= 前进 |
| FN+F3= 邮箱 | FN+F7= 网页刷新 | FN+F11= 播放停止 |
| FN+F4= 搜索 | FN+F8= 网页停止 | FN+F12= 播放器 |
- FN加ESC 长按恢复出厂设置
FN + PAUSE 播放暂停当前动画。可暂停的动画视背光模式而定。
支持 FN +WIN 锁WIN&APP，再按一次解锁，单独 LED 指示。



Quick Application Guide
快速使用指南

Mechanical Keyboard Designed by Ajazz in China. ID : ak35i-whiteLight

AJAZZ[®] × NACODEX[®]



制造商：深圳市黑爵同创电子科技有限公司
Ajazz Tongchuang Electronic Technology Co.,Ltd.
深圳市光明新区公明街道马田北路102号A栋2楼 电话:86-0755-2740 7340
2F Building A, No. 102 Matian North Road, Gongming Street, Guangming
New District, Shenzhen, China

© All rights reserved. For more information, visit <http://www.a-jazz.com>

未经许可不得盗用本包装部分或全部内容,包装所示内容均是正确的,然而基于我们不断改进技术和服务的准则,本公司保留在不预先通知的情况下更改相关内容的权利。