

尺寸:140x80mm(单张)
材质:128铜板纸、折叠式单黑



Galaxy80 产品参数

产品品牌:VTER
产品名称:Galaxy80
产品结构:板簧Gasket结构
产品尺寸:365.3x136.1x32.3mm
产品重量:≈1590g
按键数量:88Key
连接方式:有线-USB
线材长度:≈1.5M
接口:键线分离式typec接口
矩阵:全键无冲
背光:全彩RGB,19组灯效
兼容性:Windows7/8/9/10/11/Mac/Linux

- 1 -

Galaxy80 指示灯说明

- CAPS指示灯**:CAPS键白光指示
- 锁win指示灯**:WIN键白光指示
- 灯条**:默认RGB光波

Galaxy80 F13功能说明

F13键功能定义:默认为F13按键功能 可驱动自定义功能

Galaxy80 灯光效果说明

- 上电后,灯光围绕键盘跑动,拖尾熄灭,跑完所有按键后,恢复掉电前灯光状态。
- 灯光模式的点亮顺序依表格从上到下,最后切完模式后有OFF。
- 灯光效果,19组灯效

静态恒亮 | 单点亮 | 单熄灭 | 繁星点点 | 漫天飞雪 | 百花争艳 | 动态呼吸 | 光谱循环 | 彩泉涌动 | 多彩纵横 | 随便逐流 | 峰回路转 | 一触即发 | 一石二鸟 | 涟漪扩散 | 川流不息 | 重峦叠嶂 | 斜风细雨 | 来回穿梭

- 2 -

Galaxy80 按键复合功能说明

组合按键	WIN功能	MAC功能(单按触发)	描述
FN+F1	此电脑	屏幕亮度减	组合键选择MAC / WIN
FN+F2	主页	屏幕亮度加	
FN+F3	计算器	多任务控制器	
FN+F4	邮箱	程序列表	
FN+F5	播放器	无	
FN+F6	停止播放	无	
FN+F7	上一曲	上一曲	
FN+F8	播放/暂停	播放暂停	
FN+F9	下一曲	下一曲	
FN+F10	静音	静音	
FN+F11	音量减	音量减	
FN+F12	音量加	音量加	
FN+BAKSPACE	长按3s 复位	长按3s复位	键盘背光闪三次白光表示
FN+	键盘背光颜色切换	键盘背光颜色切换	顺序:七彩、红、橙、黄、绿、青、蓝、紫、白
FN+Enter	键盘背光灯效切换	键盘背光灯效切换	19种灯效,默认随波逐流
FN+右Shift	切换指示灯灯效	切换指示灯灯效	流光/光谱/呼吸/常亮/灭 默认流光

- 3 -

Galaxy80 按键复合功能说明

组合按键	WIN功能	MAC功能(单按触发)	描述
FN+T	键盘背光开关	键盘背光开关	带记忆
FN+WIN-L	锁WIN	无	无
FN+A	Win系统	Win系统	出厂默认
FN+S	Mac系统	Mac系统	无
FN+→	灯光速度变慢	灯光速度变慢	极限档位时上下左右灯闪烁3次指示
FN+←	灯光速度加快	灯光速度加快	
FN+↑	灯光亮度+	灯光亮度+	
FN+↓	灯光亮度-	灯光亮度-	

- 4 -

Galaxy80 Product parameters

Product brand: VTER
Product Name: Galaxy 80
Product structure: Leaf spring gasket structure
Product size: 365.3x136.1x32.3mm
Product weight: ≈ 1590g
Number of keys: 88Keys
Connection method: Wired USB
Wire length: ≈ 1.5M
Interface: Keywire separation type C interface
Matrix: Full key no impact
Backlight: Full color RGB, 19 sets of lighting effects
Compatibility: Windows 7/8/9/10/11/Mac/Linux

- 5 -

Galaxy80 Indicatorlightdescription

- CAPS indicator light**:CAPS key white light indication
- Lock win indicator light**:WIN key white light indication
- Light bar**: default RGB light wave

Galaxy80 F13 Function Description

F13 key function definition: by default, F13 key function can drive user-defined function.

Galaxy80 Lighting effect description

- After power-on, the light runs around the keyboard, and the tail goes out. After running all the keys, the light status before power-off is restored.
- Lighting mode lighting order according to the table from top to bottom, finally cut the mode after OFF.
- 19 sets of lighting effects

- 6 -

Galaxy80 Key complex function description

Combination key	WIN function	MAC function (single click trigger)	Description
FN+F1	This computer	Screen brightness decrease	Select MAC/WIN by key combination.
FN+F2	Homepage	Screen brightness increase	
FN+F3	Calculator	Multi task controller	
FN+F4	Mailbox	Program List	
FN+F5	Player	Nothing	
FN+F6	Stop playing	Nothing	
FN+F7	Previous song	Previous song	
FN+F8	Play/Pause	Play pause	
FN+F9	Next song	Next song	
FN+F10	Mute	Mute	
FN+F11	Volume -	Volume -	
FN+F12	Volume +	Volume +	
FN+BAKSPACE	Long press for 3 seconds to reset	Long press for 3 seconds to reset	Keyboard backlight flashing three times indicates white light
FN+	Keyboard backlight color switching	Keyboard backlight color switching	Order: Colorful, Red, Orange, Yellow, Green, Green, Blue, Purple, White
FN+Enter	Keyboard backlight effect switching	Keyboard backlight effect switching	19 lighting effects, default to follow the flow

- 7 -

Galaxy80 Key complex function description

Combination key	WIN function	MAC function (single click trigger)	Description
FN+right Shift	Switching indicator light effects	Switching indicator light effects	Streamer/Spectrum/Breathing/Always On/Off Default Streamer
FN+T	Keyboard backlight switch	Keyboard backlight switch	Factory default
FN+WIN-L	Lock WIN	---	---
FN+A	Win system	Win system	
FN+S	Mac system	Mac system	
FN+→	Light speed slows down		When in the extreme gear position, the up, down, left, and right lights flash three times to indicate
FN+←	Accelerated lighting speed	---	
FN+↑	Light brightness+	---	
FN+↓	Light brightness-	---	

- 8 -

产品质保

感谢您对VTER产品的信任和支持,为了让您放心使用产品,更好的保证您的权益。我司将严格遵守并执行相关规定,实行售后。

- 服务有效期:自购买之日起质量保证12个月,终生维护,配件不在保修范围内;
- 服务内容:按微型计算机商品维修更换退货责任规定进行服务;
- 不属于服务范围:
 - 已超出有效服务或免费维修期的;
 - 未按照正确说明使用、维护、保管导致故障或损坏的;
 - 由于不可抗力(如自然灾害等)原因造成的产品之不良;
 - 人为因素导致产品不良(如操作失误,磕碰,进水,输入不合适电压等);
 - 一切人为损坏、自行拆机、拆封标、使用不当等,不在保修范围。

合格证

VTER
合格类:
PASS

更多产品信息请关注
VTER官网
<https://www.vtergaming.com>

产品型号: _____
购买日期: _____
客户姓名: _____
联系电话: _____
联系地址: _____

执行标准:GB/T 14081-2010