

75% - 82 Keys Hot Swappable Mechanical Keyboard

MODEL	KiiBoom Phantom 81	LAYOUT	81 Keys
SIZE	330 x150 x 35mm	WEIGHT	1430g ± 20g
HOT-SWAP	YES	KEYCAPS	PBT
SYSTEMS	Microsoft Windows, Apple macOS		
CONNECTION	USB-C, Wireless 2.4G, Bluetooth 5.0		

Manufactured in China by KiiBOOM.

KiiBOOM.com

EC REP

OST_EU_20220711000049

eVatmaster Consulting GmbH

Bettinastr.30
60325 Frankfurt am Main, Germany
contact@evatmaster.com

UK REP

OST_UK_20220711000015

EVATOST CONSULTING LTD

Suite 11, First Floor, Moy Road Business
Centre, Taffs Well, Cardiff, Wales, CF15 7QR
contact@evatmaster.com



Windows SHORTCUTS

Toggle the Switch on the back to Windows mode

FN + F1	Screen Brightness -
FN + F2	Screen Brightness +
FN + F3	Task Switching
FN + F4	Explorer
FN + F5	Email
FN + F6	Homepage
FN + F7	Last Song
FN + F8	Play / Pause
FN + F9	Next Song
FN + F10	Mute
FN + F11	VOL -
FN + F12	VOL +

macOS SHORTCUTS

Toggle the Switch on the back to macOS mode

FN + F1	Screen Brightness -
FN + F2	Screen Brightness +
FN + F3	Task Control
FN + F4	Call SIRI
FN + F5	-
FN + F6	-
FN + F7	Last Song
FN + F8	Play / Pause
FN + F9	Next Song
FN + F10	Mute
FN + F11	VOL -
FN + F12	VOL +

GENERAL FUNCTION SHORTCUTS

FN+ 1	Bluetooth Device 1	FN + \	Toggle the light mode
FN + 2	Bluetooth Device 2	FN + DEL	Toggle backlight direction
FN + 3	Bluetooth Device 3	FN + ↑	Backlight Brightness -
FN + 4	2.4G	FN + ↓	Backlight Brightness +
FN + 5	USB-C	FN + ←	Backlight Speed -
FN + PgUp	Turn on/off the RGB	FN + →	Backlight Speed +
FN + P	Toggle the Sidelight mode	FN +]	Toggle the backlight color
FN + Z	Sidelight Brightness -	FN + WIN-L	Lock Windows Key
FN + X	Sidelight Brightness +	FN + ←	Check Battery
FN + C	Sidelight Speed -		
FN + V	Sidelight Speed +		
FN + B	Toggle the Sidelight color		

CHANGE RGB EFFECTS

Pressing **FN+** at the same time allows you to switch the RGB effect of your Phantom 81 keyboard

PAIRING BLUETOOTH

FN + 1/2/3 Long Press for 3 seconds to pair Bluetooth device

FN + 1/2/3 Short Press to switch to last paired device

Long press the FN+1/2/3 for 3 seconds, the keyboard will start pairing and the light will flash. If there's no connection, the keyboard will enter into sleep mode.

PAIRING WIRELESS 2.4GHz

FN + 4 Long Press for 3 seconds to pair Wireless 2.4g

FN + 4 Switch to Wireless Mode

Firstly, turn on the keyboard via the switch on the keyboard's bottom. Then plug the receiver into your device. After being recognized by your device, press and hold FN+4 for 3 seconds you will see the 4 key's backlit flashes. When the LED stays on the green, the pairing is successfully done.

BLUETOOTH & WIRELESS 2.4GHz SPECIFICATIONS

Operating system should be windows 8 or above to support the Bluetooth function. The device should support Bluetooth 5.0 or a higher version to use Bluetooth 5.0.

KEYBOARD SHORTCUTS

If you switch devices and/or systems, please make sure to toggle independent switch to change the keyboard layout according to the system you used, or some shortcuts/multimedia keys may not work properly.

KEYBOARD WAKE UP/ SLEEP



If your keyboard is sleeping press any key to wake it up, it will remember the last device connected.

DO YOU NEED ANY MORE HELP?

For technical assistance, please email to support@kiiboomb.com with your purchase order number and a detailed description of your issue.



1. Keycap Puller
2. Switch Puller
3. Switch Pins



Before installing switches, be sure the pins are clean and straight. Push the Switch Straight Down into the switch slot.
Please be gentle. Be sure the pins are aligned with the slots.

REMOVE SWITCHES

1. Grab your Switch Removal Tool and align the gripping teeth vertically (on the Y-Axis) at the center of the switch, as shown in the example graphic above.
2. Grab the switch with the Switch Puller and apply pressure until the switch releases itself from the plate.
3. Using firm but gentle force pull the switch away from the keyboard using a vertical motion.

INSTALL SWITCHES

1. Check that all the switch metallic pins are perfectly straight and clean.
2. Align the switch vertically. The pins should align themselves to the keyboard PCB.
3. Press the switch down until you hear a click. This means your switch clips have attached themselves to the keyboard plate.
4. Inspect the switch to ensure it's properly attached to your keyboard, and test it.

Note: If the key doesn't work its possible you may have bent one of the switches while installing it. Pull the switch out and repeat the process.


Pins may be damaged beyond repair and need replacement if this process is not done correctly. Never apply excessive force when replacing keycaps or switches. If you cannot remove or install keycaps or switches please contact customer service as soon as possible to avoid damage to the keyboard due to operating errors.

WARRANTY

KiiBOOM's Warranty covers any factory defects that might affect the proper functionality of your purchase. It doesn't cover any damage that may occur from normal wear and tear. If your product is defective we will send you a replacement unit. Replacement units might require you to send the defective unit back to KiiBOOM.

We provide a 1 year warranty for our products when bought from our website (KiiBOOM.com). Your item will not be covered by your 1 year warranty if the inspection shows any sign of modification or changes unsupported by the original product, these include: Changing internal components, Assembling and reassembling the product, Replacing Batteries, etc.

We will ONLY cover the item if it is bought from our official stores. You do not have a warranty with us if you bought the item from another reseller or likewise. Please contact the store that you bought your product from to resolve issues.



75% - 82键热插拔机械键盘

型号	KiiBoom Phantom 81	布局	81 键
尺寸	330 × 150 × 35mm	重量	1430g ± 20g
热插拔	YES	键帽	PBT
系统	Microsoft Windows, Apple macOS		
连接	USB-C, Wireless 2.4G, Bluetooth 5.0		

Manufactured in China by KiiBOOM.

KiiBOOM.com



OST_EU_20220711000049

eVatmaster Consulting GmbH

Bettinastr.30
60325 Frankfurt am Main, Germany
contact@evatmaster.com



OST_UK_20220711000015

EVATOST CONSULTING LTD

Suite 11, First Floor, Moy Road Business
Centre, Taffs Well, Cardiff, Wales, CF15 7QR
contact@evatmaster.com



Windows 快捷键

将后面的Switch切换到Windows模式

FN + F1	屏幕亮度-
FN + F2	屏幕亮度+
FN + F3	任务切换
FN + F4	资源管理器
FN + F5	电子邮件
FN + F6	主页
FN + F7	上一首
FN + F8	播放/暂停
FN + F9	下一首
FN + F10	静音
FN + F11	VOL -
FN + F12	VOL +

macOS 快捷键

将Switch切换回macOS模式

FN + F1	屏幕亮度-
FN + F2	屏幕亮度+
FN + F3	任务控制
FN + F4	呼叫SIRI
FN + F5	-
FN + F6	-
FN + F7	上一首
FN + F8	播放/暂停
FN + F9	下一首
FN + F10	静音
FN + F11	VOL -
FN + F12	VOL +

通用功能快捷键

FN + 1	蓝牙设备1	FN + \	切换灯光模式
FN + 2	蓝牙设备2	FN + DEL	切换背光方向
FN + 3	蓝牙设备3	FN + ↑	背光亮度 -
FN + 4	2.4G	FN + ↓	背光亮度 +
FN + 5	USB-C	FN + ←	背光速度 -
FN + PgUp	打开/关闭RGB	FN + →	背光速度 +
FN + P	切换侧灯模式	FN +]	切换背光颜色
FN + Z	侧灯亮度-	FN + WIN-L	锁定Windows 键
FN + X	侧灯亮度+	FN + ←	检查电量
FN + C	侧灯速度-		
FN + V	侧灯速度+		
FN + B	切换侧灯的颜色		

改变RGB效果

同时按FN+\可以让你切换你的Phantom 81键盘的RGB效果

配对蓝牙

FN + 1/2/3 长按3秒, 配对蓝牙设备

FN + 1/2/3 短按切换到最后配对的设备

长按FN+1/2/3秒, 键盘开始配对, 指示灯闪烁。如果没有连接, 键盘将进入睡眠模式。

配对无线2.4 ghz

FN + 4 长按3秒配对无线2.4g

FN + 4 切换到无线模式

首先, 通过键盘底部的开关打开键盘。然后把接收器插入你的设备。被设备识别后, 按住FN+4 3秒, 你会看到4键的背光闪烁。当LED灯亮绿色时, 表示配对成功。

蓝牙和无线2.4GHz规格

支持蓝牙功能的操作系统必须是windows8或以上。设备需要支持蓝牙5.0或更高版本才能使用蓝牙5.0。

键盘快捷键

如果您切换设备和/或系统, 请确保拨动独立开关以根据您所使用的系统更改键盘布局, 否则一些快捷键/多媒体键可能无法正常工作。

键盘唤醒/睡眠




如果你的键盘处于睡眠状态, 按任意键唤醒它, 它将记住最后连接的设备。

你还需要什么帮助吗?

如需技术支持, 请发送电子邮件至support@kiiboom.com, 并附上您的订单号和问题的详细描述。



1. 键帽拉出器
2. 拔轴器
3. 开关针



安装轴前, 请确保轴的针脚干净、笔直。将轴直下推入交换机槽位。请温柔, 确保针脚与插槽对齐。

移除轴体

1. 抓住你的轴拆卸工具和对齐夹齿垂直(在y轴上)在轴的中心, 如上图所示。
2. 用拔轴器抓住轴, 施加压力, 直到轴从板上释放自己。
3. 用轻柔的力量, 垂直动作将轴从键盘上拉开。

安装轴

1. 检查所有轴金属针是否完全笔直和干净。
2. 将轴垂直对齐, 针脚应该与键盘PBC对齐。
3. 按下轴, 直到听到咔哒一声。这意味着你的轴夹已经连接到键盘板上了。
4. 检查轴, 确保它正确地连接到你的键盘上, 并测试它。

注意:如果按键不工作, 可能是你在安装它的时候把其中一个轴弄弯了。
拔出轴重复上述过程。

如果这个过程不正确, 插脚可能损坏, 无法修复, 需要更换。更换键盘盖或轴时, 不要用力过猛。如果您无法拆卸或安装键盘盖或轴, 请尽快联系客服, 以避免操作错误损坏键盘。

保修

KiiBOOM的保证涵盖任何工厂缺陷, 可能影响您购买的正确功能。它不包括任何可能发生的正常磨损和撕裂的损害。如果您的产品有缺陷, 我们将寄给你们一件替换品。更换的部件可能需要您将有缺陷的部件送回KiiBOOM。

当从我们的网站(KiiBOOM.com)购买我们的产品时, 我们提供1年的保修。如果检查显示原始产品不支持的任何修改或变化的迹象, 您的产品将不在1年的保修范围内, 这些变化包括: 更换内部组件, 组装和重组产品, 更换电池等。

我们将只覆盖项目, 如果它是从我们的官方商店购买。如果您从另一个经销商或类似的地方购买了该项目, 您没有与我们保修。请您购买产品的商店联系以解决问题。