100.00 mm

130.00 mm

CIDOO 赤度

赤光度·克光界

深圳市赤度科技有限公司

地 址：深圳市光明区公明街道公明社区长春中路98号长春花园26栋104

电 话：0755-33922600

网 址：CIDOO赤度

执行标准：GB14081-2010

中国制造/Made in China

版权及声明： CIDOO 赤度 和其它赤度商标均为赤度公司所拥有的商标。并经过申请注册。所有其它商标均是其各自所有者的财产，赤度对于本产品中可能出现的任何错误不承担任何责任。本产品中包含的信息如有更改，请以实物为准，恕不事先通知。

Shenzhen Cidoo Technology Co.,Ltd
Add:. 104, Building 26, Changchun Garden, Changchun Road, Gongming Community, Gongming Street, Guangming District, Shenzhen City, Guangdong Province, China
TEL:-86- 755-33922600
Website: CIDOO赤度
Executive Standard: GB14081-2010

Copyrights and statements: CIDOO 赤度 and other cidoo trademarks are owned by Cidoo company, and may have applied for registration. All other trademarks are the property of their respective owners and Cidoo is not responsible for any errors that may appear in the product. All pictures shown are for illustration purpose only and the characteristics of the product may vary without prior notice.

产品有害物质名称及含量

为执行《电器电子产品有害物质限制使用管理办法》（中华人民共和国工业和信息化部第32号令）的相关规定要求，本产品中有害物质，按部件分类，声明如下：

产品中有害物质的名称及含量

保修卡

在购买此产品时，请您垫请填写下列信息，并加盖销售章，以保障您的合法权益。

用户信息	联系电话		电子邮箱	
	联系地址		邮政编码	
产品信息	产品名称		销售日期	
	产品型号		发票号码	
信息	商家名称		联系电话	
	通信地址		邮政编码	

注：
（1）此表应由销售商盖章填写。
（2）对于可适用相关"三包"规定的产品，本保修卡等同"三包凭证"。
（3）维修记录以授权服务机构维修凭证为准，申请服务后，请妥善保管。

欢迎您选购CIDOO V98机械键盘，希望您使用愉快，功能操作请参以下内容。

灯光设置按键

FN-↑: 背光灯效亮度增加
FN-←: 背光灯效色相减
FN---: 背光灯效速度减小
FN-BACKSPACE:关闭/开启背光灯
FN-[: 背光灯效和增加
FN-PGUP :切换LOGO灯打效
FN- space: 长按FN+ space三秒键盘恢复到出厂设置

FN-↓: 背光灯效亮度减小
FN-←: 背光灯效色相增加
FN--←: 背光灯效速度增加
FN-\:切换背光灯效
FN-]: 背光灯效和速减
FN-PGDN:切换LOGO灯颜色

QMK固件更新方法：有线模式下按往ESC上电进入 DFU模式

多媒体按键

FN-A: Windows 系统
FN-F1: 音乐播放器
FN-F3:音量加
FN-F5:停止播放
FN-F7: 播放\暂停
FN-F9:邮件
FN-F12: 搜索

FN-S: Mac 系统
FN-F2: 音量减
FN-F4: 静音
FN-F6:上一曲
FN-F8:下一曲
FN-F10: 主页FN-F11: 计算器
FN-WIN: 锁定\解锁 WIN 键

三模（有线/蓝牙5.0/2.4G无线）对码连接方法

有线模式
请将USB线插入到你的电脑设备中，模式切换拨动开关在中间即为有线模式，键盘背光灯亮起并变为默认的RGB灯效，则表示连接成功。

蓝牙对码方法：
键盘中间拨动开关拨动到左边（靠近USB接口处）即为蓝牙模式。

请按照以下步骤将键盘和您的设备进行蓝牙配对

1.CIDOO V98蓝牙键盘最多可同时连接3个蓝牙设备，打开键盘电源。（靠近USB接口处为 蓝牙模式）.按住 FN + Q 或者按住 FN + W 或者按住FN + E 3-5秒.当Q或者W或者E 开始快速闪烁，表示键盘在可连接状态。

2.在要连接的设备上打开蓝牙，搜索并选择其中一组FN + Q对应设备名CIDOO V98-1，FN + W对应设备名CIDOO V98-2，FN + E对应设备名CIDOO V98-3，点击连接配对

3.键盘与你的设备连接成功后，Q键或者W键或者E键会停止闪烁，短按FN+Q或者FN+W或者FN+E键切换已经配对好的蓝牙设备。关闭键盘电源开关蓝牙断开，重新打开电源开关，CIDOO V98会默认回连到蓝牙断开前配对的设备

2.4Ghz无线连接

键盘拨动开关拨动到右边为2.4G模式：
1. 请先将键盘拨动开关切换到2.4Ghz无线模式
2. 通过USB接口将2.4Ghz接收器插入设备，此时键盘即可正常连接并使用
3. 键盘强制对码方式：长按FN+R键进行对码，此时，R键LED灯会连续快速闪烁，此时 再将接收器插入电脑USB，即可完成强制对码，2.4G连接成功后键盘出现闪烁并恢复当前背光灯颜色

自动休眠模式

键盘无线键盘作5分钟后背光关闭，按任意按键唤醒键盘键盘无线键盘作30分钟后进入深度休眠模式，蓝牙断开，按任意按键将退出深度休眠模式，RGB背光亮起并回连蓝牙

充电指示及电量显示：

当键盘的电池电量很低时（电池电量低于3.4V）FN键会持续闪烁红灯，提醒键盘需要充电
按下FN+ 右SHIFT可查询电量及充电状态，查看后键盘1↑至0）亮起，分别代

表10%到100%电量，如右SHIFT键显示红灯，代表键盘正在充电，如右SHIFT未显示红灯，则代表键盘已充满电或未充电...松开FN+ 右SHIFT即可退出查询模式。

自定义设置

CIDOO V98支持QMK/VIA 程序改键布局

注意：请确保您的键盘已正确插入电脑设备
VIA 安装步骤如下：
1.请访问https://github.com/WestBerryVIA/via-releases选择您需要的最新的VIA软件然后下载并安装在电脑上 .如下图

2.从赤度官网下载CIDOO V98.JSON文件并上传到VIA软件。打开VIA软件后：点击Load 导入JSON文件 如下图

3.如下画面表示VIA软件安装完成并成功连接.

如果VIA软件无法识别您的键盘，请联系我们的客服人员寻求帮助如果您的键盘已经插入，VIA会自动检测你的键盘是否兼容。键盘记忆是持久的，这意味着无论你在哪里插入键盘，它都会记住设置。在VIA软件页面上半部分，鼠标点击选择你想要更改的按键，然后再用鼠标点击VIA软件页面下半部分中你所想要更改的按键，这按键功能生效。

更多设置板块请见以下说明：

宏设置
CIDOO V98按键中没有设置宏按键，在此可以通过VIA软件映射宏按键到你想要的按键上，实现宏快捷操作。
CIDOO V98默认配置了0-3层4个层级，每个单独的按键都可以拥有多个功能，这对于较小的键盘来说重要，因为它只没有足够的按键来实现所需的所有功能。

特殊设置
在此可以通过按键变更功能将特殊按键替换到你想要的按键上，实现该功能的快捷操作。

其他客制化
CIDOO V98提供其他功能按键的客制化改键

CIDOO V98默认定制的0-4层键盘布局图
层0：当你使用键盘连接到Win系统设备时，层0将被激活使用
层0：当你使用键盘连接到Mac系统设备时，层0将被激活使用，其中按键
Left Alt=Left Option Left Win=Left Command Right Alt= Right Option

---

V98

95% QMK Tripple Modes CNC Aluminum Mechanical Keyboard

层1：当你使用键盘连接到Win/Mac系统设备时，长按MO(1)按键层1将被激活使用

层2：当你使用键盘连接到Win/Mac系统设备时，通过VIA改键设置任意按键为MO(2)保存后，长按MO(2)按键层2将被激活使用

层3：当你使用键盘连接到Win/Mac系统设备时，通过VIA改键设置任意按键为MO(3)保存后，长按MO(3)按键层3将被激活使用

minimalistic design inheriting the originality style
THIS IS EXACTLY WHAT I LIKE THANK YOU

Thank you for purchasing our QMK /VIA V98 mechanical keyboard . We hope you will be pleased with both the product and service you received The following is a detailed introduction of the functions and operation method of this product.

Default Hot Keys
Hold FN + listed keys to activate

LED Setting Keys

FN_.> : LED backlight brightness Increase
FN+ .< : LED backlight brightness decrease
FN+ .: : LED backlight hue increase
FN+ "" : LED backlight hue decrease
FN + [(: LED backlight speed increase
FN)] : LED backlight speed decrease
FN+BACKSPACE: Toggle ON/ OFF Backlight
FN+\: Toggle LED light mode
FN+V: LED backlight saturation increase
FN+C: LED backlight saturation decrease
FN+Z : Toggle LOGO LED light mode
FN+X: Toggle LOGO LED light color
FN+ space: Long press FN+ Space for 3 seconds to reset the keyboard to the factory setting.

FN+A: Windows System   FN+S: Mac System
FN+F1: Music Player   FN+F2: Volume -
FN+F3: Volume +   FN+F4: Mute
FN+F5: Stop   FN+F6: Previous
FN+F7: Play/Pause   FN+F8: Next
FN+F9: Email   FN+F10: Web
FN+F11: Calculator   FN+F12: Search
FN+WIN : Lock/unlock WIN key

Device Firmware Upgrade Mode : Hold ESC key in wired mode and plug in cable

---

USB Wired/BT5.0/2.4G Tri Mode Pairing Method:

Wired Mode:
Please toggle the mode switch to middle (wired mode). and then insert USB cable into your computer, the keyboard backlight lights on and turns to the default of RGB backlight effect, it means connection successful.

Bluetooth® Pairing Instructions:
Perform the following steps to pair this keyboard with your device(s).

1.This Bluetooth keyboard can be paired with up to three devices at the same time. Please toggle the mode switch to the Bluetooth mode .(From left to right are BT →Wired →2.4Ghz). Q key or W key or E key will flash .

2.Long press FN + Q or FN+W or FN+ for 3~5 seconds to enter pairing mode. At this time, the Q/W/E key will flash blue quickly indicates that keyboard is ready to connect.

3.Open the Bluetooth settings on your device and scan for available devices. Locate and select the device name entry. "CIDOO V98-1" for FN+Q ；"CIDOO V98-2" for FN+W , "CIDOO V98-3" for FN+E .

4. Once the keyboard has connected to your device, the Q/W/E key will cease flashing, and light on after Bluetooth pairing was successful. Short press "FN" and "Q" or "FN" and "W" or "FN" and "E" keys to switch paired Bluetooth device.

The Bluetooth connection has memory . It will disconnect when power off the keyboard ,and the keyboard will re-connect to the last device when power on the keyboard again.

2.4G mode Usage method:

1.Please toggle the mode switch to 2.4Ghz mode . From left to right are BT → Wired→ 2.4Ghz T. "R" key will flashes green .

2.Plug the receiver into USB port of the device .The "R " key will cease flashing and the keyboard backlight turns to the default of RGB backlight effect, it means connection successful.

2.4Ghz pairing instruction

The keyboard 2.4Ghz mode is default paired . If you need to re-pair 2.4Ghz mode , Please perform the following operations :
Long press FN+R key enter 2.4g pairing mode . At this time, "R" key flashes green color quickly. Insert 2.4G dongle to USB port . After the connection is successful, "R" key stops blinking and goes to steady color and turns to the default of RGB backlight effect, it means connection successful.

Auto sleep mode

In Bluetooth and 2.4G mode, after 5 minutes without key press ,the backlight will turn off to conserve the battery , any key press will be awaken the keyboard.

In Bluetooth mode, the deep sleep mode will be entered after 30 minutes without key press, and the Bluetooth is disconnected. Press any key to exit the deep sleep mode, and the RGB back light will turn up and connect back to Bluetooth.

Battery Charging Indicator:

When the battery power of the keyboard is low (the battery power is less than 3.5V), the FN key will keep flashing red reminds low battery .

Battery level check

 Press and hold FN+ SHIFT_R can check the battery and charging status , Battery level indicator .From !1 to)0 stands for 10%~100% (estimate only) un-hold to exit .

Right SHIFT key light on red indicate that keyboard is charging ; Right SHIFT

Key will back to default backlight when fully charged or un-charge .

Custom Configuration

CIDOO V98 supports remap the keys via QMK/VIA firmware in wired mode and 2.4G mode
Note : Make sure your keyboard is properly plugged into your computer device

VIA installation steps see below :
1.Please visit "https://github.com/WestBerryVIA/via-releases/releases" to download the latest VIA application for your computer's OS here .

2.Download JSON files from CIDOO website and click load to Import JSON file accordingly .See following photo.

3.Installation is completed and VIA software connected successfully if show below picture .

Key will back to default backlight when fully charged or un-charge .

Custom Configuration

CIDOO V98 supports remap the keys via QMK/VIA firmware in wired mode and 2.4G mode
Note : Make sure your keyboard is properly plugged into your computer device

VIA installation steps see below :
1.Please visit "https://github.com/WestBerryVIA/via-releases/releases" to download the latest VIA application for your computer's OS here .

If the VIA software cannot recognize your keyboard, please reach out our support to get the instruction.

VIA automatically detects your compatible keyboard if it's plugged in. Keyboard memory is persistent, which means that wherever you plug in keyboard, it remembers the settings.

On the top half of VIA software, choose one key by your mouse, and then select the key that you wanted on the bottom half of VIA software, and it was effected.

Firstly switch to VIA software key tester table, there is not any background color before you press any keys, when you want to test this key you have programmed, press it and the background color will change to red color means it works, otherwise it is not work.

See below for more information about configuration

Macros setting

CIDOO V98 does not have physical multimedia keys, you can remap the keys through the VIA software to achieve the function.
CIDOO V98 is configured with 4 layers from 0 to 3 by default, and each individual key can have multiple functions.
This is important for smaller keyboards, where there aren't enough physical keys to do all the functionality you need.

Special keys setting
Here you can remap the key to replace the special key to the key you want, to achieve the quick operation of the function.

CIDOO V98 VIA software provides many different RGB lighting effects by default. You can change the lighting brightness, speed, color and customize the lighting effect you want. You can also change the key to operate the lighting effect you set.

Others custom
CIDOO V98 provides other customized remap to other functional keys.

CIDOO V98 default customized 0-3 layer keyboard layout.

Layer0: This layer will be activated when your keyboard connected to the Windows system.
Layer0: This layer will be activated when your keyboard connected to the Mac system.
Left Alt=Left Option Left Win=Left Command Right Alt= Right Option

Layer1: This layer will be activated when your keyboard's system toggle switched to Windows or Mac and press Fn1(3) key.

Layer2: This layer will be activated when your keyboard's system toggle switched to Windows or Mac and keymapped any keys to MO(2) and then press it.

Layer3: This layer will be activated when your keyboard's system toggle switched to Windows or Mac and keymapped any keys to MO(3) and then press it.

Key description

Hue+	Hue Increase	2.4G...	2.4Ghz Mode
Sat+	Light Saturation+	Brght+	Backlight Increase
RGB M6+	RGB Mode Next	Lock Win	Lock Windows Key
RGB Tog...	RGB Toggle	USB Mode	Switch to USB Mode
Win...	Windows Mode	Brght-	RGB Speed Decrease
Mac...	Mac Mode	Brght-	Backlight Decrease
Hue-	Hue Decrease	RGB SPI	RGB Speed Increase
Sat-	Light Saturation-	Fn1(3)	Layer 1
BT1	Bluetooth Device 1	MO(2)	Layer 2 will be activated when holding this key
BT2	Bluetooth Device 2	MO(3)	Layer 3 will be activated when holding this key
BT3	Bluetooth Device 3		

保修声明

感谢您对我司产品的信任与支持，为了切实让您用好产品，更好地保障您的权益，我司竭尽全力开好付开封闭实现屋实行售后服务：

服务范围：按照我们现对商品维修更换政策售后规范进行服务

以下不涉及保内之范畴

（A）误用、滥用或不适当的贮藏；

（B）维护不正确；例如将不得不在不适当的温度、湿度或其他不当环境条件下使用，不可比力试验外事件，网络或其余网络事件可引起故障之类损坏；

（C）非授权人员擅自修理或改装；

（D）任何第三方产品或配件改；

（E）用户于非指定或授权因；

（F）以其他也无产品使用的持性设备式或其他设备老化；以超载、撞伤以及突变损伤时间，造成问题机理性任何故障，原产发而且所引起的损坏不保证过，不在此限；

以上因外力引起产品于出此外损或，且仅在中因大须设备异议或磨，本保证将不提供或因相关素材时，造极法完全同损也其有他后所料，本文件的任何内容不包含而上述的实物而表面或受行任何不可约不明确或

产品保修信息

产品名称	保修范围	部件维修	保修期（月）	保修服务类型	客注
CIDOO V98	主要部件	键盘	12	寄送维修	

注释和说明：
只是根据本产品有限保修对客户承诺，产品说明保修政策及实施产品服务期和限制期，本政策及实施的标准而适用于不同地区的法律法规，如有您购买地的国家/地区法律允许或要求不同于本政策。